















Kolpa-san[®]

by KOLPA



- SI** Montažno navodilo
- HR** Upute za montažu
- BIH** Upute za montažu
- SRB** Uputstva za montažu
- BIH** Uputstva za montažu
- CG** Uputstva za montažu
- MK** Инструкции за монтажа
- HU** Szerelési utasítás
- GB** Assembly instructions
- DE** Einbauanleitung
- RU** Инструкция по монтажу
- FR** Instruction d'assemblage



Tip: PANDORA - P1301







Demontaža / Dissmounting





3



- 4x $\varnothing 12$
- 1x
- 2x






Nastavitve / Adjustment



Montaža / Mounting












Nastavitve / Adjustment




4

- 1x PUSH
- 2x
- 8x
- 2x
- 1x
- 1x
- 2x
- 1x



Nastavitve TIP ON
The adjustment for TIP ON



demontaža
dismounting
abclipsen
démontage

